

Parts List for 362 Type 1

Item Number	Part Number	Description	Qty Required
1	881026	ARMATURE	1
1	860973	ARMATURE 115V	1
1	845948	BAFFLE	1
1	839325	FAN VACUUM	1
2	881027	FIELD	1
2	860972	FIELD 115V	1
3	883191	BRUSH & SPRING	2
3	803483	BRUSH CAP	2
3	873497	BRUSH HOLDER	2
4	876770	SWITCH	1
5	839549	CORD	1
5	875863	CORD	1
5	879758	CORD-EURO	1
11	803876	BEARING	3
12	803846	BEARING	3
12	804211	BEARING	3
15	855284	BEARING	3
23	801852	SEAL	1
31	D839309	GEAR DRIVEN	1
31	839308	PINION DRIVE	1
37	903840	DRIVE PULLEY	1
37	862604	BELT	1
40	861323	DRIVE SHAFT	1
40	804531	SHAFT & LEVER	1
53	864434	COVER GEAR HSG	1
54	839292	COVER DRIVE BEL	1
57	882350	HANDLE SET	1

COPYRIGHT© 2005. All Rights Reserved.

Parts list, pricing, and availability subject to change. Please visit www.dewaltservicenet.com for current parts information.

Parts List for 362 Type 1

Item Number	Part Number	Description	Qty Required
59	839326	COVER	1
64	839306	FRAME PROTECTOR BAR	1
65	823466	DRIVE PULLEY	1
65	861322	PULLEY	1
67	865164	DUST SCOOP	1
68	826229	SCREW	1
84	696085	KNOB SET	1
85	886538	SCREW	10
90	692639	DUST BAG	1
90	696167	DUST BAG ASSY-	1
93	876108	ADJ SCREW	10
93	876108	ADJ SCREW	10
200	839352	SCREW WASHER	10
202	882671	ELBOW/SUPPORT KIT	1
202	882671	ELBOW/SUPPORT KIT	1
203	877967	BAG SUPPORT	1
203	839330	SPRING ELBOW RE	10
204	849314	TERM	1
205	877967	BAG SUPPORT	1
206	802695	SCREW	10
207	879678	SCREW	10
208	882185	SCREW MACHINE STEEL	10
209	883485	SCREW	10
212	865643	SCREW	10
213	844107	SCREW	10
214	803496	WASHER	10
215	843081	SCREW	10

COPYRIGHT© 2005. All Rights Reserved.

Parts list, pricing, and availability subject to change. Please visit www.dewaltservicenet.com for current parts information.

Parts List for 362 Type 1

Item Number	Part Number	Description	Qty Required
216	839293	COVER COMMUTATO	1
218	848148	SCREW	10
219	882036	SCREW	10
221	802289	SCREW	10
222	839307	GASKET GEAR HSG	1
223	801372	NUT	10
224	883479	SCREW	10
227	839305	SPACER	10
228	838312	SCREW	10
229	802607	SCREW	10
230	878262	SCREW	10
231	893792	SCREW	10
232	847318	SCREW	10
233	839348	SCREW	10
234	861571	362 SPEC PLATE	1
235	802589	SCREW	10
236	802318	WASHER	10
237	839315	SPACER LEVER	10
238	823254	NUT	10
239	803341	WASHER	10
240	803365	CAP	1
241	804424	KEY	1
242	802942	RING	10
243	860191	IDLER HOUSING	1
244	839311	SLIDE COVER	1
245	839276	LINK LEVER ASSB	1
246	839314	SPRING TORSION	10

COPYRIGHT© 2005. All Rights Reserved.

Parts list, pricing, and availability subject to change. Please visit www.dewaltservicenet.com for current parts information.

Parts List for 362 Type 1

Item Number	Part Number	Description	Qty Required
247	839316	SPACER LINK	10
248	804424	KEY	1
250	861434	CORD CLAMP	1
253	802433	PIN	10
254	802886	SPRING	10
255	690671	SPRING	10
255	690671	SPRING	10
256	804415	WASHER	10
257	804204	SHOE	1
258	908909	SHOE ASSY	1
259	908909	SHOE ASSY	1
260	876384	SCREW	10
261	803317	WASHER	10
263	878813	SCREW	10
268	861434	CORD CLAMP	1
269	810716	RELIEVER	1
270	859227	SCREW	10
281	803104	LEAD	1
282	839300	FAN	1
800	801946	LUBE	1
800	801945	TUBE GREASE	1

COPYRIGHT© 2005. All Rights Reserved.

Parts list, pricing, and availability subject to change. Please visit www.dewaltservicenet.com for current parts information.